

COVID-19 VACCINE STORAGE



STORAGE TEMPS

Some vaccines— will reportedly **require** extremely cold storage temperatures, with some as low as minus 94 degrees Fahrenheit (minus 70 degrees Celsius)

- 94 °F (-70 °C)



TEMPERATURE SENSORS


Primex OneVue Sense™ Temperature Sensor with a cryogenic temperature probe **can monitor temperatures as cold as minus 324.4 degrees Fahrenheit** (minus 198 degrees Celsius)

- 324.4 °F (-198 °C)

REAL-TIME ALERTS

OneVue monitoring technology can send you **real-time call, text and email alerts** as well as **visual and audible**

notifications if temperatures within your vaccine storage area leave a specified range.



REPORTING

OneVue eliminates manual logging, and also maintains compliance with regulatory reporting requirements.



www.primexinc.com/vaccine-storage